



Pre-Installation Reminder for HVM BCU 2.0

Thanks for your continued support! To simplify wiring and avoid opening the cover, we've upgraded the BCU design. Please go through the following points before installing BCU 2.0.

1. Prepare Your Tools

Make sure you have a **hydraulic crimping tool** on hand. You'll need **6mm² and 10mm² hexagonal dies**. If you don't have one, we recommend getting the YQK-70, which includes both die sizes.



YQK-70 Hydraulic Crimping Tool



Hexagonal Dies Set (6mm² and 10mm²)

2. Check Die Compatibility

The YQK-240 model listed in the manual might not have standard 6mm² and 10mm² hex dies. Use YQK-70 or make sure your tool is equipped with the correct dies.

3. Crimp Terminals Cleanly

Watch the crimping instruction video first (scan the QR code in the manual). If there are burrs after crimping, trim them with diagonal pliers before inserting into the connector.



4. Follow Updated Wiring Sequence

The comms line sequence has changed from BCU 1.0. Please follow the new wiring order in the manual when connecting to the inverter.

5. Need Help?

If anything goes wrong during installation, don't hesitate to contact our partner ALPS:

+61 2 8005 6688

service@alpspower.com.au